



Plug & Charge Mode

Enabling with mobile

A step-by-step guide for your Brim Charger.

This guide walks you through connecting directly to your Brim charger (AP Mode) to enable Plug & Charge. This allows charging to start automatically, without needing an app or RFID card.

Before you start stand near the charger and have the following ready:


- Wi-Fi Password
- PIN Code

Step-by-Step Instructions

1

Connect to the Charger's Hotspot

In your phone's Wi-Fi settings, connect to the network named after your charger's serial number (e.g., **SN1005...**). Enter the Wi-Fi Password from your user card.



Wi-Fi list




Password entry

2

Log in with Pin


Open a web browser (e.g., Safari) and go to **192.168.4.1**. On the login screen, enter your charger's PIN Code and tap Login.




3

Navigate to setting


Tap: 1) Charger Settings → 2) Basic settings → 3) Charging Modes Switch.



Home screen




Charger Settings menu



Basic settings list

Enable Plug & Charge

In the pop-up, select **Plug to charge** and tap **Confirm**. Then scroll down and tap the main **Save** button to apply the change.



Plug to charge selected